SUZUKI with X24C01 and OKI memory
IMMO EMULATOR



In Universal Julie emulator solder jumpers **J2 and J5**



In Universal Julie emulator solder jumpers **J1 and J5**

*** Sometimes, OKI and X24C01 programs work interchangeably**

Use

ECU with OKI memory read as 93LC56
ECU with X24C01 memory



Find OKI eeprom memory, read and save as 93LC56.



In OKI eeprom memory
write 01 01 values in addresses:

04 – 05 08 – 09 0C - 0D
10 – 11 14 – 15 18 - 19

Find X24C01 eeprom memory





In address from 04 to 0F write 01 value

Examples of connections






Copyright © 2012 Iwona Piotrowska
CODE
GND
+5V


CODE


GND
+5V
EH35





Immo line e.g. socket B pin 15

In different ECU types, the immo line can be in different pins. You check connection between ECU pin and pin 9 of 16-pin OBD socket with a multimeter.

Power supply 5V from capacitor near memory.

Warning!!!

Due to possible construction changes of cars, check signals with multimeter in the ECU plug.

We state that we are the only authentic authors of this manual. We possess copyright of this publication. All rights reserved. Unauthorized copying, hiring, lending, public performance will be punished!!! Any trials of unauthorized copying, hiring, quoting prohibited!!! Both service and advertisement constitute copyright and they are the subject to the protection in accordance with the Act from 4th Feb. 1994 on Copyright and Related Laws (Statute Book no. 24 position 93) and protection on the basis of the Act from 8th June 1993 on combating an unfair competition (Statute Book no. 47 position 211)

www.carlabimmo.com

Last updated 05.09.2014