

---

# Honda

Select the model:

Model Accord

Model Shuttle



Model HRV

Model Legend

---

## Model Accord

Use this board and clip:





- Remove the cluster and open it.
- Look for the 8 pin chip 93C56.
- Look for the silver chrystal and join its contacts.
- Connect the clip to Port 1.
- Put the clip on the chip 93C56 (red on pin 1).
- Select the menu **Honda-Accord**
- The Tacho Universal shows you the old value.
- Select the menu **Adjust KM.**
- Enter the new value.
- Verify the new value with **OK.**

---

## Model Shuttle

Use this board and clip:




- Remove the cluster and open it.
- Look for the 8 pin chip 93C46.
- Look for the silver chrystal and join its contacts.
- Connect the clip to Port 1.
- Put the clip on the chip 93C46 (red on pin 1).
- Select the menu **Honda-Shuttle**
- The Tacho Universal shows you the old value.
- Select the menu **Adjust KM.**
- Enter the new value.
- Verify the new value with **OK.**

---

## Model HRV

Use this board and clip:





- Remove the cluster and open it.
- Look for the 8 pin chip 93C46.
- Look for the silver chrystal and join its contacts.
- Connect the clip to Port 1.
- Put the clip on the chip 93C46 (red on pin 1).
- Select the menu **Honda-HRV**
- The Tacho Universal shows you the old value.
- Select the menu **Adjust KM.**
- Enter the new value.
- Verify the new value with **OK.**

---

## Model Legend

Use this board and clip:



- Remove the cluster and open it.
- Look for the 8 pin chip 93C46.
- Look for the silver chrystal and join its contacts.
- Connect the clip to Port 1.
- Put the clip on the chip 93C46 (red on pin 1).
- Select the menu **Honda-Legend**
- The Tacho Universal shows you the old value.
- Select the menu **Adjust KM.**
- Enter the new value.
- Verify the new value with **OK.**